
This quality manual was created by SHOP-TECH

Copyright 2004, All Rights Reserved

Reproduction or distribution for fee of this CD-Rom or unique portions thereof is strictly prohibited without a license. Reproduction or distribution for personal use is permitted provided that this permission notice is included at least once in all copies and the appropriate copyright notices are retained. All other rights reserved.

SHOP-TECH techplans@yahoo.com

Building a Teardrop Sleeper Trailer



Even the movie colony has become "trailer conscious"

—photo shows Ida Lupino, famous movie star, entering a streamline trailer.

for \$50.00

For the summer vacationist or motoring enthusiast who enjoys frequent outings, but who cannot afford frequent hotel bills or expensive camping equipment, a "teardrop" trailer, which comfortably accommodates two persons, will prove just the thing for many pleasant week-end trips. This can be built for approximately \$50 by anyone who has ordinary carpenters' tools.

By C. M. GEORGE

THE cost of the trailer described here is figured with sides, windows and door cut at a mill. If one has access to a jig-saw and band-saw large enough to handle the job, a little expense can be saved on these items. Prices mentioned here are actual costs.

Wheels, rims, springs and axle of a light car, such as a Chevrolet of about 1928, '29 or '30 model, are suitable for the running gear. The rear shackle and front frame hanger are left connected to

the springs for welding to the frame.

Framework for the bed of the trailer can be made at any welding shop, as is shown in Fig. 2. Main support and strength is obtained from the two cross members of 1/4" x 3" angle iron 42" long. Each end is cut, bent back at right


angles and drilled for $\frac{1}{2}$ " hole as shown. Cross bracing of $\frac{1}{4}$ " x 1" strap iron adds rigidity while assembling, as well as reduces twisting motion when on the road. The strap iron braces are welded where they cross.

The tongue is made of channel iron about 7½ feet long (the size for a Model T Ford frame). Resilience of the frame steel reduces the chance of breaking the tongue.

As the running gear is finally assem-

bled, the tongue should be attached so that the spring shackles are at the rear and the frame hangers are at the front. This improves the trailer's pulling quality. The tongue is welded in the three places where it touches the frame, to give added strength.


A malleable steel



Small and neat, yet serving the purpose for which it was built.

ball and socket hitch can be obtained from a mail order house for the price listed. This bolts on to the end of the tongue.

The ball is attached to the car by fastening it to a threaded forged steel eye, which in turn is bolted through a hole





Construction expense may be further cut down if one is able to do his own welding.

The trailer bed stringers are fastened to the metal frame with four \(\frac{1}{2}'' \times 3 \frac{1}{2}'' \) carriage bolts. The heads of the bolts are countersunk. Note that the weight is approximately nine inches off center. With the weight bearing on the rear of the car, the trailer "rides" better than if it were perfectly balanced.

Corners of the 2" x 3" frame are nailed with 20-penny cement coated box nails.


Fig. 1—This diagram (below) shows how the sides are laid out.





Hooked up to the car and ready to go on that "long trip"; and the owners will be entirely unmindful of hotel bills.

Further rigidity can be obtained by placing 6" steel corner braces in each corner, although this is not required. The front 2" x 3" member crossing the tongue is



Three-quarter view of the trailer. This, when painted with aluminum paint, makes an attractive job.

bolted to it with the bolt head countersunk to allow for the flooring.

The flooring (of second grade lumber) is nailed cross-wise with cement coated nails. Use of cement coated nails reduces chance of the boards working loose.

The sides of the compartment are cut from standard ½"x8'x4' pieces of presdwood. Two pieces are tacked together where the nail holes will be in waste material, and the windows, door and curve of the "teardrop" are plotted as in Fig. 1. Material cut from the windows should be saved for use in making the

frames. Other left-over presdwood should be saved also for the window frames.

To give rigidity to the presdwood, $1'' \times 6''$ surfaced wood is applied along the inside bottom of the sides as in Fig. 3 with $3/4'' \times 11/2''$ vertical bracing as




Fig. 2—The angle iron cross braces should be welded, as explained in the accompanying text.

shown. Boards are then cut about 2" wide to fit around the curve to which the roof is attached. All these are glued with casein glue and nailed with 3/4" box nails.

The two sides are then nailed into

place flush with the bottom of the 2" \times 3" members and bolted with three $\frac{1}{4}$ " \times 4" carriage bolts on either side.

Tops of the three vertical siding braces may be left short enough to allow cross pieces of the same

material, the width of the floor, to be attached. Use of three 6" corner braces on either side between side reinforcements and floor, adds materially to the strength of the sides.

Material for the roof is cut the proper width from presdwood and attached, beginning at the front. It is nailed and glued as it is bent over the curve. Presdwood is very easy to curve properly, and is rigid when fastened in place.

It will take two pieces to make the roof, as the presdwood comes only in

8-foot lengths. The first piece will reach about to the rear window. Therefore a light piece of wood must be glued and nailed under the seam. The second piece is applied just as was the first. The front and rear ends are bolted with two carriage bolts each.

The door is braced as shown in the drawing and is fitted with hinges in the ordinary manner. A night-lock (costing as little as 75 cents at a mail order house) provides an excellent latch.

Windows are made by cutting six circles, with inside diameter of 11", from the material saved from cutting the large circular holes. From the left-over presdwood, other circles with inside diameters of 11" and outside diameters of 13" are cut.

Two large sheets of heavy celluloid can be obtained from an auto-top shop or mail order house. From these, six 12" circular pieces are cut and nailed between the two frames.


The windows are then fitted on the inside of the compartment and hinged at


the top to open upwards. All six windows do not necessarily have to open, but at least two should be hinged for proper ventilation.

The whole exterior of the trailer is painted with aluminum paint, which

gives a weatherproof as well as good-looking finish. On the inside, the bracing may be painted a color harmonizing with the brown panels of the presdwood or left unfinished.

(Continued on page 90)








Fig. 3—The thin wooden sides will require some sort of braces. This shows a suitable arrangement.

Building a Teardrop Sleeper Trailer

(Continued)

A Model T Ford tail light and license plate holder assembly, bolted or screwed to the back member of the trailer, works entirely satisfactorily. This must be put on upside down in order to hold the license plate the legal distance above the ground. A double wire is run to the tail light of the car, allowing enough slack for right-hand turns. One wire is grounded to the body of the car and the other is spliced to the line to the battery.

Although no bed springs are included in the plans for this sleeper, a thick mattress on the flooring assisted by the trailer springs, enables very comfortable sleep. A two-foot space at the rear end provides ample room for two suitcases.

Anyone desiring to put more money into a trailer such as this, could elaborate upon the "minimum essentials" given here. Some additional ideas could include:

1, Bed springs or box mattress; 2, Construction of back portion of roof so it could be raised, and extra space at rear used as a table; 3, Installation of reading light; 4, Curtains for windows; 5, A shelf or sling from roof for carrying clothes, etc.

1001 101 carrying clothes, etc.	
MATERIAL LIST AND APPROXIMATE	COST
Wheels, axle, springs	\$12.00
Rims	1.00
Tires (second hand)	5.00
Lumber	
2x3 three pieces 8 ft	.45
1x4 tongue and groove flooring (second grade),	
13 pieces 8 ft	2.10
13 pieces 8 ft	.65
Welding (labor and material)	10.00
Presdwood	
Four pieces 8'x4' @ 6½c sq. ft	8.32
Trailer hitch	2.00
Celluloid for windows	
Two large sheets, heavy @ 69c	1.38
Aluminum paint (1 quart)	.90
Lock for door	.75
Tail light (Model T Ford assembly)	
Wiring	
	.48
12 ft. @ 4c Connector plug	.15
	.13
Hardware	0.0
Six 6" corner braces @ 15c	.90
Four 1/2 x 3 1/2 carriage bolts @ 10c	.40 1.00
Ten 1/4 x4 carriage bolts @ 10c	
One pair galvanized hinges for door	
Six small hinges for windows	
Waterproof casein glue	.25
Waterproof casein glue	1.00
17111 W U1 K	1.00

TOTAL

000

1936 Model




1940 Model with Kitchenette




1953 Model with Kitchenette


Other Trailer Plans Available




1937 Runlite



Pop-Up Campers



1951 Li'l Guy



(Canvas top and hard top)